

ReVo Leveler Simple Instructions – initial setup

Install the nest on the RV.

Slide ReVo Leveler onto the nest.

Connect the tow vehicle to the RV.

Level the RV left to right.

Press the power button to turn on ReVo Leveler.

Press and hold the function button for 5 seconds.

Press and hold the L/R button until display shows “- - - -”.

Release the L/R button, display will show “good”.

Raise the RV to the proper disconnect height.

Press and hold the DIS button until display shows “- - - -”.

Release the DIS button, display will show “good”.

Disconnect the tow vehicle and drive clear of the RV.

Level the RV front to back.

Press and hold the F/B button until display shows “- - - -”.

Release the F/B button, display will show “good”.

Raise the RV to the correct connect position.

Press and hold the CON button until display shows “- - - -”.

Release the CON button, display will show “good”.

Press the power button to turn off ReVo Leveler.



www.revoleveler.com

info@revoleveler.com

Toll free: 844-RV Level

844-785-3835

ReVo Leveler Simple Instructions – Usage

Locate the RV on the campsite.

Place ReVo Leveler on the nest.

Press the power button to turn on ReVo Leveler.

Press and release the L/R button once.... Display shows “????”.

Press and hold the L/R button a second time. Release the button when the display shows “- - - -”. The display will show a numerical value and directional arrow.

Place board(s) of the displayed value thickness under the low side wheels of the RV.

Pull the RV up onto the board(s).

Press and hold the DIS Button. Release the button when the display shows “- - - -”. Display then shows jack travel value and direction arrow.

Prepare the RV to be disconnected from the Tow Vehicle.

Raise the RV until ReVo Leveler shows two solid green arrows.

Disconnect and move the tow vehicle clear of the RV.

Press and hold the F/B Button. Release the button when the display shows “- - - -”. Raise or lower the RV until ReVo Leveler shows two solid green arrows.

Press the power button to turn off ReVo Leveler.

Place ReVo Leveler in storage bin.

Enjoy your camping stay.

When ready to leave that site, install ReVo Leveler on the nest.

Press the power button to turn on ReVo Leveler.

Press and hold the CON Button. Release the button when the display shows “- - - -”.

Raise or lower the RV until ReVo Leveler shows two solid green arrows. Connect the tow vehicle to the RV.

Press the power button to turn off ReVo Leveler.

Remove ReVo Leveler from the nest and place it in a storage bin.